

substance	disinfectants	
manufacturer	Anios	Antiseptica Dr. Hans-Joachim Molitor GmbH
		Aquagenius Schweiz GmbH
		B. Braun Melsungen AG
		Bode Chemie GmbH
		cosiMed GmbH
		DAN MORE
		DESOMED
		DR. SCHUMACHER GMBH
		DR. Weigert
		Ecolab Deutschland GmbH
		GAMA Healthcare Ltd.
		JOYA International
		Lyoform
		Medical Service Höber GmbH & Co.H
		OPTIMUM11 GMBH
		orochemie GmbH + Co. KG
		Pepler GmbH
		PINO GmbH
		Reckitt Benckiser
		SARAYA EUROPE
		Schülke & Mayr GmbH
		Tana Chemie GmbH
quick-acting disinfectants		
name of disinfectant	SURFA SAFE	Antiseptica Kombi Flächen Des.
	Biguacid Plus	Biguacid-S
	Descocogen® Liquid	Descocid®-N
	ASECAdes	Meliseptol® rapid
	Meliseptol® SF	Hexaquart® S
	Meliseptol® foam pure + fresh	Bacillo® AF
	Bacillo® AF	Bacillo® 30 Foam
	Bacillo® 30 Foam	Bacillo® 30 Tissues
	Kohrsolin® extra Tissues	Mikrobac® forte
	Mikrobac® forte	Mikrobac® Tissues
	cosiMed Schnelldesinfektion	cosiMed Desinfektionstücher
	ANTIGONE WIPES	DESOMED® RAPID UNIVERSAL
	DESOMED® RAPID UNIVERSAL	BIGUANID FLACHE N
	CLEANISEPT®	DESCOCEPT SENSITIVE WIPES
	DESCOCEPT AF	DESCOCEPT AF
	OPTISAL® N	OPTISEPT®
	OPTISEPT®	neoform MED rapid
	neoform MED rapid	Incidin® Active
	Incidin® Active	Incidin® Foam
	Incidin® Foam	Incidin™ OxyWipe
	Incidin™ OxyWipe	Incidin™ OxyWipe S
	Incidin™ OxyWipe S	Incidin® PLUS
	Incidin® PLUS	Incidin® Liquid Spray
	Incidin® Liquid Spray	Incidin™ Rapid
	Incidin™ Rapid	Incidin® Pro
	Incidin® Pro	Sani-Cloth® Active - Tücher
	Sani-Cloth® Active - Tücher	Clinell Alcohol Wipes
	Clinell Alcohol Wipes	Clinell Universal Wipes
	Clinell Universal Wipes	JOYA®
	JOYA®	Aldasan® 2000
	Aldasan® 2000	Clorina®
	Clorina®	Fugaten®
	Fugaten®	Hospisept® - Tuch
	Hospisept® - Tuch	Lysoformin®
	Lysoformin®	Lysoformin® spezial
	Lysoformin® spezial	Trichloro®
	Trichloro®	MSH-CLEANER
	MSH-CLEANER	BESTWIPES
	BESTWIPES	B10
	B10	Micro Clean
	Micro Clean	Micro Clean Foam
	Micro Clean Foam	Immix Clean
	Immix Clean	Septapin® AQUAQUICK
	Septapin® AQUAQUICK	Septapin® Wipes
	Septapin® Wipes	SAGROTAN® Hygiene-Spray
	SAGROTAN® Hygiene-Spray	Alpet D2
	Alpet D2	mikrozyd® AF liquid
	mikrozyd® AF liquid	mikrozyd® AF wipes
	mikrozyd® AF wipes	mikrozyd® sensitive liquid
	mikrozyd® sensitive liquid	mikrozyd® sensitive wipes
	mikrozyd® sensitive wipes	perform®
	perform®	pursept® -A Xpress
	pursept® -A Xpress	terralin® liquid
	terralin® liquid	terralin® protect
	terralin® protect	TPH protect
	TPH protect	APESIN rapid
	APESIN rapid	
Article		
AMALFI phthalatfrei	■	■
TORINO phthalatfrei	■	■
CORDOBA ACTICIDE® phthalatfrei	■	■
PERI phthalatfrei	-	■
CHICAGO M ACTICIDE® phthalatfrei	-	■
PAVONA phthalatfrei	-	■

result: The disinfectants should not be changed.
comment: Only use one disinfectant and rinse with clear water: Never use a mixture of various disinfectants!
 As we have no influence on the production and raw materials of the disinfectants, we can give no general guarantee of resistance.

- Cleaning prior to disinfection:**
- Clean using lukewarm water and a microfibre cloth.
 - Remove more stubborn marks with a PH-neutral soap.
 - Rinse the soap with clear water.
 - NEVER use detergents, solvents (alcohol), strong soap, bleaching or scouring agents: these can affect the synthetic leather and reduce the lifespan!
 - Blood stains have to be removed immediately with cold water.
 - Remove massage oil immediately with PH-neutral soap.
 - Do not use leather maintenance products containing oil or grease.
 - After disinfection, rinse the surface with water.

appendix:
 ■ disinfectants resistant
 - disinfectants not resistant