

AMALFI · CHICAGO · CORDOBA · PERI · PAVONA

DEUTSCH

Verarbeitung

- Keine Lösungsmittelklebstoffe verwenden!
- PES Vlies 40 g/m² zwischen Kunstleder und Polsterschaum einlegen.

Reinigung

- Neutrale Seifenlauge und handwarmes Wasser verwenden.
- Mit einem Mikrofasertuch in kreisenden Bewegungen reinigen.
- Hartnäckigere Flecken mit einer weichen Bürste und Seifenlauge in kreisenden Bewegungen behandeln.
- Oberfläche anschließend mit einem feuchten Mikrofasertuch und handwarmem Wasser abwischen.
- Oberfläche abtrocknen!

Nicht verwenden

Keine Lösungs-, Bleich-, Scheuer- oder Lederpflegemittel einsetzen!

ENGLISH

Instructions

- Do not use solvent adhesives!
- A 40 g/m² PES non-woven between PU upholstery foam and the vinyl is recommended.

Cleaning

- Clean the surface with lukewarm water and a neutral soapy lather.
- Moisten a microfiber cloth and remove dirt using circular movements.
- Treat stubborn marks with a soft brush moistened with lukewarm soap suds.
- Wipe the cleaned surface with a damp microfiber cloth soaked in clean lukewarm water.
- Dry off the surface!

Do not use

No solvents, bleaching agents, abrasive or scouring agents, or leather care products should be used.

AMALFI · CHICAGO · CORDOBA · PERI · PAVONA

DEUTSCH

Reinigung vor und nach der Desinfektion

- Vor der Desinfektion öl- und fetthaltige Rückstände mit einer pH-neutralen Seifenlösung entfernen.
- Erst danach die Materialoberfläche desinfizieren.
- Lauwarmes Wasser und ein Mikrofaser Tuch verwenden; Seifenreste mit einem feuchten Tuch entfernen.
- Auf keinen Fall Reinigungsmittel, Lösungsmittel (Alkohol), aggressive Seifen, Bleich- oder Scheuermittel verwenden.
- Blutflecken umgehend mit kaltem Wasser entfernen.
- Keine Lederpflegemittel verwenden, die Öle oder Fette enthalten.
- Nach der Desinfektion die Oberfläche mit Wasser abwischen.

Wichtige Hinweise

Viele Bekleidungstextilien besitzen unzureichende Farbechtheiten. Anfärbungen durch Jeans oder andere Textilien sind von jeglicher Herstellergarantie ausgeschlossen.

Die aufgeführten Hinweise sind keine Garantie und befreien den Anwender nicht von seiner Sorgfaltspflicht im Umgang mit Materialien und Reinigungsmitteln.

Geprüfte Desinfektionsmittel

Die aktuelle Liste der geprüften Desinfektionsmittel finden Sie in der separaten Desinfektionsmittelempfehlung.

ENGLISH

Cleaning before and after disinfection

- Remove oily and greasy residues with a pH-neutral soap solution before disinfection.
- Disinfect the material surface only after cleaning.
- Use lukewarm water and a microfiber cloth; remove soap residue with a damp cloth.
- Never use detergents, solvents (alcohol), strong soaps, bleaching or scouring agents.
- Remove blood stains immediately with cold water.
- Do not use leather care products containing oil or grease.
- Rinse the surface with water after disinfection.

Important information

Many clothing textiles have insufficient colour fastness. Stains caused by jeans or other textiles are excluded from any guarantee.

These recommendations are not a guarantee and do not absolve the user from a responsibility of due care when dealing with materials and cleaning agents.

Tested disinfectants

The current list of tested disinfectants is available in the separate disinfectant recommendation.